


# PARVATI

## (Szafa / Skriňa / Szekrény)



















Ⓟ	Instrukcja montażu
Ⓓ	Aufbauanleitung
Ⓒ	Assembly instruction
Ⓚ	Návod na montáž
Ⓗ	Szerelési útmutató

Karta gwarancyjna
der Garantieschein
Guarantee certificate
Záručný list
Garancialevél




	Wymiar / Size / Rozmer / Méret	X
1	1990x620	1
2	1990x620	1
3	1568x619	1
4	1568x619	1
5	1877x500	1
6	776x500	5
8	1566x80	2
9	1857x800	1
10	1990x80	2
11	1442x80	1
12	1910x800	2

### Akcesoria - Accessories - die Accessoires - Príslušenstvo - Tartozékok







A  x1	B  x26	C  x12	D  x12	F 3.5x13  x20
G 4x25  x4	H  x2	I  x20	J  x1	K  x2
M.  x35	P.  x8	U  x4	U1  x8	U2  x4
V  x10	W  x2			



24x




B



5

B




C

3


D

5

4




4x





C



4x

D
















U2



U1

