



TOVI 120

(Szafa / Skriňa / Szekrény)
























PL	Instrukcja montażu	Karta gwarancyjna
D	Aufbauanleitung	der Garantieschein
GB	Assembly instruction	Guarantee certificate
SK	Návod na montáž	Záručný list
HU	Szerelési útmutató	Garancialevél









	Wymiar / Size / Rozmer / Méret	X
1	1868x500	1
2	1868x482	1
3	1868x500	1
4	358x482	1
5	1196x500	1
6	1196x500	1
7	1898x409	2
8	384x242	2
9	400x150	2
10	400x150	2
11	300x150	2
12	405x330	2
13	1862x384	2
14	1370x384	1
15	386x482	3
16	509x482	1
17	1898x374	1


















Akcesoria - Accessories - die Accessoires - Príslušenstvo - Tartozékok


A	B	C	D	E	L
 x1	 x34	 x18	 x18	 x6	 x9
F 3.5x13	G 4x25	H	N 3.5x16	J	I
 x24	 x8	 x4	 x10	 x2	 x12
O	S	M.	K	LA	
 O1  O2  O3  O4	 x5	 x100	 x2	 x22	
	DR	EL	WE		
	 x1	 x2	 x1		













8x D



6x D

